深圳市明仕达智能光电有限公司					
SHENZHEN BRIGHT STAR INTELLIGENT LIGHTING CO. LTD					
UPS+PS Switching power supply with Battery Charger(UPS Function)					
			Storago an	d working condition	
MSD-AC1	0236E		Model	MSD-AC10236E	
	Manufacturer		Working tem.	-20°C~55°C	
AC input Customization Rated power Output voltage Emergency Po			Storage tem. RH	-40 C -+85 C 10%-90%	
			Working Altitude	<5000m	
			Atmospheric	70-106Kpa	
			Cooling mode	cooling by fan	
Features	1.High efficiency: On-line single-conversion from power supply the terminal equipment, Energy saving12%~20%.				
	 2.Low cost: The PUS has the UPS inside, and do not need to purchase extra battery devices.One integrated UPS to drive the terminal equipment. Save at least 40% cost. 3.High reliability: From Ac mains to the Terminal Equipment implemented by one conversion and ruduced failure rate.Battery discharge directly to the terminal equipment without second 				
	boost conversion. Battery more stable by reducing the series connection of the battery quantity. 4.When working with AC mains, the energy is directly transferred to the load by reducing voltage conversion.Meanwhile the battery is under standby mode, this will save extra cost. The battery will start to work when the AC mains' voltage below 187VC smoothly(online design).				
	5.Small volume Battery inside the power supply, compact size design				
	 6.Smaller volume of the battery High efficiency: Working at the same time, more than 12% efficiency compared with traditionI UPS solution. Battery capacity:cut down 20% compared with UPS conditional UPS solution. 7.Battery with high reliability Brightstar's battery do not have the boost and connect in cories with 241/or 1211/based on the 				
	output power). The less connection of the battery quantity, the higher stability of the battery.				
AC Input	Input rated voltage 220VAC Input voltage range 180V~240VAC				
	Frequency Input current	47Hz~63Hz 6-11A			
	Leakage current Standby power consumption	≦ 0.75mA, 220Vac nsumption ≤10W			
hattery input	Input rated voltage		DC2	4V 28V	
	Input current	70Amax			
	Efficiency	1000W AC≥90%; DC≥92% (@50%load)			
	Output voltage Output current	+36V 27.7A			
Output	voltage tolerance	+36V: 34.2~37.8V <+5%			
	Ripple	≤1070 ≤300mV			
	Power factor capacitive load(Max)	≥0.9@50% load ≤ 20000uF			
Characteristic of battery charging			charging voltage 27.5-28V		
The	1,Maximum discharge currer	nt of batte	ry 70A		
characteristic of	2,Battery stop discharge	Standard battery design: the battery stop discharge at 21±0.5V(can be customized) and turn off; When under Emergency, it can set			
operation when	3,When Ac mains' voltage b	below 187V, the system' signal indicates that the Ac Mains Output is ains' voltage return to normal when the voltage up to 192VAc) :Ac			
voltage is low	mains source and battery do not work at the same time which can save energy; The PSU with				
Protection	Output protection	OPP	120%~160%(hiccup mod troubleshooting).Power	e and recover automatically after supply working	
			condtition≤120% rated The power supply will co	power. me into the hiccup mode when	
		SCP	short circuit the positive output.Recover to work	and negative of the after troubleshooting.	
	Battery group protection	Battery low	The battery will shut dow below 21±0.5V Leakage	vm when the discharge voltage	
		voltage Battery	When the battery workin	ng, it's fuse will fuse and cut off	
		SCP	the shortcircuit problem	of the battery.	
Insulation	1、Insulation voltage (AC input to DC output): 2000Vac/5mA/60s 2、Insulation voltage (L-N-G): 1500Vac/5mA/60s				
	3、insulation impedance :AC input to DC output/AC input to Battery input>50MΩ				
	1、Ac mains operation condition:180V~240VAC				
Startup	2、A. Without Ac mains source, the battery can start up by itself(21-28V);				
conditions and	B. Usually, the Ac mains source and the Battery exist at the same, the ac mains source is prior and charging the battery. The power supply convert to the battery working mode when the Ac				
work process	mains's voltage drop down to 60-85% of it's rated voltage(Origional setting 70%). The working mode converter to the ac mains working source when it's voltage increase to 75% of the rated votlage. The converter voltage point is below 85% of the rated voltage.				

Communication Interface



Definition of RS232 interface 1. **RXD** 232 Signal delivery

2. TXD power supply(232signal reception)3. GND

4. +5V output

Monitoring terminal diagram监控端子图

• Connecting to the Pin 1-3 if do not need extra +5V supply. If it need display external, connecting pin 4(pin 4 output current \leq 500mA, current tolerane \pm 5% and the output is non-isolated).

• The output signals of RS232 interface: the voltage of AC mains source, the working conditions of Ac mains source and batteries, low voltage of battery, open-circuit of battery, SC of battery, the breakdowm of AC mains source, low voltage of AC mains, battery charging, Charging circuit failure, temperature of the battery.

RS232.

• The host computer can issue commands to the power supply through the RS232 interface, and perform functions such as forced emergency, monthly inspection, and annual inspection.

• The forced start function: When Ac working and the battery in good condition, short circuit the forces start interface, the working mode change from ac mode to battery mode immediately, and the battery cut off voltage is 18.5 ± 0.5 V. Without AC, the battery can drive the terminal equipment by short circuit the forced start interfaced.

• Battery temperature detection: The power supply detects the battery temperature through an external sensor. When the temperature more than 60 ± 5 °C, the power supply will command the battery stop charging or stop discharing&cut cut off the output.

 5.9
 250

 Image: Section of the action of the acti

The power supply is design for the ac mains working all year around. It has self protection in case of the ac mains break off or unstable. The working time of the battery based on the volume of the load as well as the volume of the battery.